

High power, high wallplug efficiency room temperature continuous wave quantum cascade lasers

**R. Maulini, A. Lyakh, A. Tsekoun, I. Dunayevskiy, R. Go,
and C. Kumar N. Patel**

Pranalytica, Inc., 1101 Colorado Ave., Santa Monica, CA 90401

C. Pflügl, L. Diehl, Q. J. Wang, and Federico Capasso

School of Engineering and Applied Sciences, Harvard University, Cambridge, MA 02138

X. J. Wang, J. Y. Fan, and T. Tanbun-Ek

Adtech Optics, Inc., 18007 Cortney Court, City of Industry, CA 91748

**International Quantum Cascade Lasers School & Workshop
Monte Verita, Switzerland**

September 17, 2008



Acknowledgements

**This work was supported in part through
DARPA Contract No. W911QX-07-C-0041:
Efficient Mid-Wave Infrared Lasers (EMIL)
(Approved for Public Release, Distribution
Unlimited)**



Outline

- **High-power QCL design**
- **Introduction**
- **Pranalytica's 4.6 μm high-power QCLs**
- **Pranalytica's high-power QCL packaging**
- **Reliability of high-power QCLs**
- **Widely tunable high power external cavity QCLs**



Introduction

QCLs have mainly been used in point chemical sensors

High power QCLs in the first atmospheric window open up new applications:

- Infrared countermeasures (IRCM)
- Free space optical (FSO) telecommunications
- Remote sensing
- Ultra-sensitive trace gas detection using photoacoustic spectroscopy
- Non-linear frequency conversion (e.g. THz generation)



QCL Design

For CW/RT active region can heat up to 400K


- Higher threshold current
- Lower slope efficiency

Design optimization includes

- A. Optimization of gain region for high-temperature operation
- B. Optimization of heat dissipation




A. Gain Region Design



- Increased ΔE_{43} : improved injection efficiency to level 3
- Increased ΔE_{21} : reduced thermal population of level 2

Pranalytica's 4.6 μm Gain Stage Design


Typical two-phonon design



$E_{32} = E_{21} = \text{LO phonon energy}$

Modified two-phonon design (patent pending)

$E_{32} = \text{LO phonon energy}$
 $E_{21} \cong E_{21'} > \text{LO phonon energy}$




- $E_{21} \neq \text{LO phonon energy} \Rightarrow$ more flexibility for design optimization
- Increased $E_{31} \Rightarrow$ reduced electron back scattering for lower laser level 3
- Increased $E_{54} \Rightarrow$ increased injection efficiency for upper laser level 4

Design: Pranalytica (A. Lyakh)



B. Optimization of Heat Dissipation




InP has higher thermal conductivity than active region:

- Exclusively InP waveguide
- BH with InP regrowth

Epi-down mounting

- AlN submount, AuSn solder

Pranalytica's 4.6 μm High-Power QCLs



Appl. Phys. Lett. **92**, 111110 (March 2008)





Integrated Package for QCLs

Requirements:

- Capable of dissipating heat of high power CW QCLs
- Capable of lowering device temperature with respect to case temperature (hermetically sealed)
- M-LWIR compatible optics
- High reliability
 - Fluxless assembly
 - No epoxies, glues, etc.
 - Well-characterized, long lifetime must be demonstrated at the package level

Fully Packaged CW/RT 4.6 μm High Power QCLs



High Power CW/RT 4.6 μm Laser system




May 6, 2008

Pranalytica, Inc.

12




Hermetically Sealed QCL Package Results




1.55 W (1 facet), 13.5 % efficiency

Is BH processing really necessary?




0.83 W (1 facet), ~8 % efficiency

Cryogenic temperature performance




4.1 W, ~24 % efficiency


Reliability of high power QCL with metallic HR coating



Reliability of high power QCL with dielectric HR coating



Burn-in effect: Buried-Heterostructure devices




Increase of maximum power

Decrease of threshold current & roll-over current

Attributed to a reduction of leakage current in lateral regrowth




Burn-in effect: Ridge waveguide devices



No burn-in effect observed




Widely tunable high power external cavity QCLs



Single-frequency tuning range = 163 cm^{-1}
Maximum wallplug efficiency = 5%

Tunable external cavity QCLs: Etalon scan



Free spectral range = 0.77 cm⁻¹
Scan resolution = 0.04 cm



Thank you
Questions?

